

Torch Computer System (v71) brief fitting instructions:

- Insert Torch ROM "CPN71+" into any ROM socket in the host machine
- With short ribbon cable, connect the Z80 commicator board to the Tube interface connector under the keyboard
- Switch on the host - this also powers the Z80 communicator board
- Type *CPN [return]
at the command prompt
- Wait for the prompt 0A>
It will report if it can't find the Z80 board, and you should check the ribbon cable carefully if this is the case.
- Type MODE 0 [return]
- Type HELP [return]

This will display a list of built in commands available under Torch CCCP version 0.90